


NOTES:

1. BEFORE POURING CONCRETE ASSURE DOGHOUSE STABILITY, LEVEL, AND PLUMB.
2. USE SOLID CONCRETE BLOCKING FOR DOGHOUSE SUPPORT.
3. WAIT A MIN. OF 24 HOURS AFTER POUR BEFORE BACKFILL PLACEMENT.
4. BENCH TO HAVE SMOOTH FINISH WITH SLOPE OR FALL TO THE SPRINGLINE.
5. CUT PIPE AT THE SPRINGLINE.
6. POUR/INSTALL 4,000 PSI CONCRETE 12-INCHES ABOVE THE HIGHEST PIPE.
7. TWO ROWS OF GREENSTREAK HYDROTITE WATERSTOP OR APPROVED EQUAL SHALL BE WRAPPED AROUND ALL PENETRATIONS WITHOUT BOOTS IN ACCORDANCE WITH THE MANUFACTURER'S INSTRUCTIONS AND RECOMMENDATIONS.
8. BOOT MAY BE USED IF CONCRETE IS POURED A MINIMUM OF 12" BELOW THE INCOMING PIPE

MANHOLE CONSTRUCTED ON EXISTING SEWER (DOGHOUSE)

N.T.S.

REVISION	BY	DATE
1 ADD WATERSTOP, CONCRETE		01-16-09



SANITATION DISTRICT NO. 1

1045 Eaton Drive
FT. Wright, Kentucky 41017
Ph: (859) 578-7460
Fax: (859) 331-2436

DATE:
MARCH 2010

STANDARD
DRAWING NO:

106